


Please strictly follow the instructions to operate the reading light and ensure that it functions properly.

1. Keep the reading light if you have not used it for a long time after it has been fully charged.
2. Recharge the reading light if you have not used it for a long time after it has been fully charged.
3. Do not disassemble the product by yourself. Repairs must be performed by professional.



PRODUCT INTRODUCTION

- 1 4 Super Bright LED
- 2 ON/OFF and Color temperature adjustment button
- 3 Transparent Base Clip
- 4 USB dock
- 5 USB charging port
- 6 Main Unit

OPERATION

Continuously pressing the button

- Press once for warm light(2800k)
- Press twice for natural light(4500k)
- Press three times for white light(6000k)
- Press four times to turn off the light

Press sustain the button

- Press once for 40% brightness
- Press twice for 80% brightness
- Press three times for 100% brightness

SPECIFICATIONS

Material: ABS&Metal

Input voltage: DC5V/1A

Color temperature : 3 Colors

Ra: ≥ 95

Battery Capacity: 300mah

Charging time: 3H